



Cleaning Instructions – Synthetic Finish

It is imperative that these instructions are adhered to from handover to avoid affecting your DYNAMIK warranty.

Specialist Cleaning solutions should be used to maintain your DYNAMIK Sports Floor as detailed below. Please contact DYNAMIK to purchase the cleaning solutions or for more information.

These instructions must be followed and undertaken by a competent person and training records should be kept.

Regular checks must be made to ensure that cleaners are using the correct cleaning products, that the specified cleaning regime is being followed and that records are being kept. These checks should be carried out by someone other than the cleaner, and if the correct products are not being used or machinery is not working, or the floor is becoming dirty or slippery then this should be reported to the relevant person.

We recommend the use of a scrubber dryer for an effective cleaning regime. The floor must not be subjected at any time to any amount of standing water.

In order to maintain your floor, you will need the following:

- Scrubber dryer
- Red pads
- V Mop
- Cleaning and maintenance products



Cleaning

Daily Cleaning

Collect and remove all surface dust and debris using a V Mop. The V mop must be kept clean and dust free at all times to maintain its effectiveness.

Weekly Cleaning

The floor should be mechanically cleaned once a week or every 35 hours of use.

- Collect and remove all surface dust and debris using a V Mop as per daily clean.
- Clean the floor with SuperSport Cleaner as per the manufacturer's guidelines.
- We recommend the use of a standard speed rotary scrubber dryer (150 – 250 rpm) with a red pad.
- One side of a pad will clean approximately 100m² of floor surface. Therefore, each pad should be turned over or changed to ensure a new side of pad is used to clean each 100m².
- At the end of each cleaning session these pads should be washed thoroughly ready for future use.

Deep Clean *

You may find that your floor will benefit from a deep clean every 3 – 6 months.

- Collect and remove all surface dust and debris using a V Mop as per daily clean.
- Clean the floor with SuperSport Deep Clean as per the manufacturer's guidelines.
- We recommend the use of a standard speed rotary scrubber dryer (150 – 250 rpm) fitted with a red pad.
- One side of a pad will clean approximately 100m² of floor surface. Therefore, each pad should be turned over or changed to ensure a new side of pad is used to clean each 100m².
- At the end of each cleaning session these pads should be washed thoroughly ready for future use.

* The frequency of when such works need to be carried out depends on the hours of use of the facility, the quality of the day to day maintenance regime and whether or not the floor is protected during non-sporting events.

General Advice

- Remove spills of tea, coffee, squash etc. with a cloth dampened in warm water. Heavier contamination such as body fats, dirt and grease should be removed using a 'low foam' mild detergent, and then wiped with a clean damp cloth.
- Resilient floors can be damaged by solvents and any spillages or stains must be wiped up immediately as they may damage the surface.
- The above should be taken as a general guide since each individual facility can vary, for example if there is an excessive amount of airborne dust a more frequent cleaning regime will be required.
- Should you have any questions then please do not hesitate to contact DYNAMIK Sport.



